

DWF File Creation from AutoCAD

Open the plot dialog box by clicking File.. Plot

Change the printer driver to DWF Eplot.

Configure all settings to desired output size.

Create a ctb or stb plot style that creates all pens as black.

If screens are required, then use pen 8 for a medium screen.

Check for proper scale of drawing.

Always preview the drawing before creating a DWF.

Click 'Plot' to create DWF.